



Accumulateur Seiko® Horopart.
Seiko® Horopart capacitor.
Seiko® Horopart Akkumulator.
Acumulador Seiko® Horopart.
Accumulatore Seiko® Horopart.
Acumulador Seiko® Horopart.

Réf./Item		Pile/Battery	Calibres
S302324Y.HO		MT920	5K22A - 5K25A - 5K2JA - V142A - V145A - V14JA - VS32
S302624X.HO		MT621	V137
S302726T.HO		MT516	V110A



Accumulateur Citizen®.
Citizen® capacitor.
Citizen® Akkumulator.
Acumulador Citizen®.
Accumulatore Citizen®.
Acumulador Citizen®.

Réf./Item		Pile/Battery	Calibres
CT295.28		MT621	8510 - 8627
CT295.29		MT920	0850A - 0855A - 0870A - 0875A
CT295.33		MT621	8511A - 8512A - 8515A - 862A - 8626A - 8628A - 8629A - 8651 - 8730
CT295.34		MT920	7820A - 7870A - 7872A - 7875A - 7877A
CT295.38		MT920	C601 - C605 - C615